Remington Arms Company, Inc. 870 Remington Drive PO Box 700 Madison, NC 27025-0700 (336) 548-8700 800-243-9700

REMINGTON

Arms Company, Inc.

MODEL 341 BOLT ACTION RIFLE

- Shooting Safety Commandments
- Information
- Instructions for Operation & Care of Rifle
- Components Parts Listing
- Value and Reference Book Listing

NOTE: We are pleased to accommodate your request for the Model 341 Bolt Action Rifle information. The following documentation represents all information available on this model from the Remington Arms Co., Inc.

DO NOT MAKE CHANGES OR ALTERATIONS TO ANY PARTS OF A FIREARM. USE ONLY REMINGTON PARTS. NEVER MAKE AN ADJUSTMENT TO THE TRIGGER, OR CHANGE THE SHAPE OR SIZE OF THE SEAR, SEAR NOTCH, OR OTHER PARTS.

evril angula di 778

Antigany Amas Company, inc

- 1. Always keep the muzzle pointed in a safe direction.
- 2. Firearms should be unloaded when not in use.
- 3. Don't rely on your gun's "safety".
- 4. Be sure of your target and what is beyond it.
- 5. Use correct ammunition.
- 6. If your gun fails to fire when the trigger is pulled, handle with care!

instructions for Oneration & Care of Ride

modemnodif

- 7. Always wear eye and ear protection when shooting. The control of the control o
- 8. Be sure the barrel is clear of obstructions before shooting.
- 9. Do not alter or modify your gun, and have guns serviced regularly.
- 10. Learn the mechanical and handling characteristics of the firearm you are using.

s entities. Entibliowing detraction represents all information or claime on this medel from

INSTRUCTIONS FOR OPERATION AND CARE OF THE

Remington,

MODEL 341 BOLT ACTION REPEATING RIFLE



SPORTMASTER

SPECIFICATIONS

Made to Handle .22 Short, Long and Long Rifle Cartridges

BARREL LENGTH: 24 inches

OVERALL LENGTH: 41½ inches

TAKE-DOWN LENGTH: 24 inches

WEIGHT: Approximately 6 pounds

SIGHTS: Front, White metal bead

Rear, Buckhorn with adjustable step

STOCK AND FORE END: American Walnut

MAGAZINE: Tubular under barrel

CAPACITY: 22 Shorts; 17 Longs; 15 Long Rifles

This rifle is targeted to shoot center at 25 yards with the rear sight set in the lowest notch.

REMINGTON ARMS COMPANY, INC.

ILION, NEW YORK, U.S.A.



Remington



ASSEMBLE GUN: Place barrel A into stock C so that trigger B projects into guard D. Bo sure barrol seats firmly against end of slot in stock displant second drawing barrel and stock firmly together. (Fig. 1).


PUT BOLT INTO RECEIVER: Hold trigger back. Insert bolt into receiver E. If carrier retards it, depress carrier. If still retarded, bolt is in uncocked position. Place flat piece of metal or coin in slot (Fig. 4). Swing bolt

to left until extractor stops against coin. Continue to swing bolt until firing pin is cocked. Remove coin and close bolt. LOAD MAGAZINE: (i'ig. 2). Turn knurled plug G to left. Pull out until opening il is uncovered. Insert cartridges, lead forward until visible at opening H. Close tube upon cartridges, ro-

tating slightly for passing over shell heads. Turn plug G to lock in closed position.

LOAD BARREL: Lift bolt. Pull back to stop causing carrier to raise cartridge level to barrel. Push bolt forward to put cartridge in barrel. Turn bolt handle fully downward to right locking breech.

FIRE: Gun will now be fired by pulling trigger.



REPEAT: Proceed as in loading barrel. This extracts empty shell and gun is ready to fire again on a desamixance

SAFETY: (Fig. 3) Turn safety Jupward to vertical position, locking firing pin and intercepting line of sight.

UNLOAD WITHOUT FIRING: Put gun in safety position. Open bolt. Eject cartridge from barrel. Remove magazine tube. Tip gun to pour cartridges from front end of magazine. Replace and lock tube. Close bolt to put last cartridge into barrel. Eject it from gun which will them be entirely empty.

SINGLE LOAD WITHOUT USING MAGAZINE: Open bolt to full stop position. Push forward part way to release carrier. Depress carrier. Insert cartridge into barrel. Close and lock bolt to fire. REMOVE BOLT FROM RECEIVER: Hold trigger back. Open and withdraw bolt from receiver.

UNCOCK FIRING PIN: Be sure gun is empty. while closing boit or pull trigger on empty chamber.

CARE OF GUN

Exclusive use of Remington Kreanbore or Peters Pustless Ammuni tion reduces care necessary to keep our in condition.

TRANSLATOR: Is riveted into carrier and cannot be removed with-

INNER MAGAZINE TUBE: Remove from gun. Drive out pin and remove knurled plug. Rotain magazine spring and follower from springing out.

OUTER MAGAZINE TUBE: Remove screw from left side near front end of receiver. Pull tube forward from ring in bottom of barrel. Magazine ring and support screw may be removed, but when replaced they must not be turned in sofar as to swell bottom of hole into bore.

ASSEMBLING

Assemble in reverse order of above. Align all parts so that holes show a clear passage before replacing pins or screws, thus preventing binding and other damage.

MODEL 341 - P

This is the same as 341 but open sights are omitted. Globe front and peep rear sights are substituted for target shooting. (Fig. 5). Barrel has two screw holes for globe sight instead of dovetail slot for open front sight. No holes are provided for a sight on rear end of barrel. Receiver has two screw holes in rear left side for attaching peep rear sight. One screw has a knurled head and peep hole to be interchanged with peep disc when a larger peep aperture is desired. Peep sight adjustment is made for elevation by loosening knurled binding screw on left then tightening screw. Windage adjustment is made by loosening knurled peep disc and sliding to right or left to desired graduation, then tightening peep disc. To remove bolt, loosen side binding screw, swing peep sight to vertical position, allowing bolt handle to pass under it.

MODEL 341 - NRA

Same as 341-P with sling attached to stock (Fig. 5). Sling is shown in tight position.


CARRYING SLING ADJUSTMENT: To lengthen shoulder adjustment, release hook and draw strap thru lower swivel until long enough for shoulder to rass between gun and sling. Catch hook in nearest holes.

SHOOTING SLING ADJUSTMENT: (Fig. 6) Move forward hook to proper holes; then test length by passing hand and arm thru long loop. Move loop well upon upper arm. Slip keeper close to arm. Move hand forward and press tightly between strap and fore end to form a firm brace for holding gun. If lower end of sling inswes too tightly margine thest, book may be roughly land to land hand.

If old fashioned ammunition is used, clean bore immediatel ter shooting. Use cloth saturated with Remington Powder Solv If this is not available, pour one pint of boiling water to barrel to dissolve residue. Use small funnel to prevent spil. ing. Wipe clean and dry. Lubricate with good quality oil, free from acid to prevent custing. Remington Oil is especially prepared for this purpose. When storing gun, lubricate inside and out with heavy grease. Remington Gun Grease is prepared expecially for this purpose. Interior of barrel should be cleaned free of grease before firing to ease the passage of bullets, and prevent a swelled bore or injury to barrel. Lubricant should always be maintained on cocking cams in bolt.

Always turn bolt handle fully downward for proper locking of breech to prevent misfires which may otherwise occur. Very cold weather causes excessive heavy oil to congeal and retard fir-


ing pin action enough to cause misfire. Remove heavy oil with gasoline and substitute (sparate ingly) very thin oil. Interior of receiver. especially near front end of carrier should be treated in the same way. Bolt assembly of this gun is nothing against



terchangeable with that of any other gun. If a new bolt is needed, return complete gun to the factory or to a qualified service station. Firing short cartridges in long rifle chamber may cause ong rifle shells to stick in chamber when fired. or attacming peep pear sight,


DISMOUNTING AND ASSEMBLING deso besisab el soul

STOCK: Loosen screw F (Fig. 1). Lift barrel from stock. BOLT: Remove bolt from receiver. Be sure firing pin is cocked. Lay bolt upon a block. Drive out safety pin from rear end. Remove safety with friction washer. Uncock firing pin by holding forward part of bolt firmly and turning bolt handle to right. Drive out two pins from sleeve and cam pin from handle. Remove sleeve, handle, main spring, follower, and firing pin from rear end of bolt. Drive out extractor pin. Remove extractor, spring and plunger. Push ejector into large hole of bolt. Tip ejector from rear of bolt.




CARRIER AND TRIGGER: Drive out sear and trigger pins from receiver. Remove parts thru bottom slot. Retain friction spring and plunger in carrier.

CARTRIDGE STOP: Drive out pin at front end of carrier and remove stop.



COMPONENT PARTS (See Lists)



MODEL 341 BOLT ACTION REPEATING RIFLE

COMPONENT PARTS (See Illustrations)

In ordering parts, specify model, caliber, part number, part name and serial number of your rifle.

All parts marked with an asterisk (*) must be fitted at factory or service station.

Part No.		Price List	Part No.	Pri Lis	
401	*Barrel	\$4.00	94	Safety Shaft Friction Washer \$0.	
5 01	*Barrel (341-P and 341-NRA)	4.00	9.5	Cafair Clara Di	10
302	*Bolt	1.50	350	- 1 (주): (2) 1 [4] [4] [4] [4] [4] [4] [4] [4] [4] [4]	50
6	Bolt Extension Sleeve Pin	.10	51	Sear Pin	10
87	Bolt Sleeve	.50	77 1/2	CI:C. (A.) \ (A.)	.20
307	*Bolt Handle	1.25	352	Stock4	00
308	Buttplate	.30	452	Stock (341-P and 341-NRA) 4 (00
309	Buttplate Screw (2)	.10	76	Stock Swivel Screw (341-NRA)	10
310 }	하는 사람들 가는 것이 없는 경영을 하게 되었다. 그 사람들은 사람들에게 되었다는 것이 되었다. 그는 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그	2.50	453	Take-Down Screw	10
313	Carrier Friction Spring	.10	- 454	Take-Down Screw Escutcheon	10
88	Carrier Friction Spring Case	.10	/////////////////////////////////////	Trigger	40
89	Carrier Friction Spring Plunger	.10	336	Trigger Guard	40
14	Carrier Pin	.10	59 60	Trigger Guard Screw (2)	10
317 18	Cartridge Stop	.40		Trigger Pin	10
319	Ejector	.10	362	Trigger Spring	10
221	Extractor	.40		Trigger Spring Plungerbe Front Sight (341-P and 341-NRA)	10
22	Extractor Pin	.10	429		
323	Extractor Spring	.10			40 85
- 24	Extractor Spring Plunger	.10	98	Front Sight Screw (2).	33
325	Firing Pin	1.00			10
26	Firing Pin Cam Pin	.10	99	Front Sight Reticule .070' aperture	
29	Front Sight	.25		(341-R and 341-NRA)	10
473	Front Swivel Screw (341-NRA)	.10	100	Front Sight Reticule .110 aperture	
74	Front Swivel Screw Nut	1667) 1676, 1		(341-P and 341-NRA)	10
	(341-NRA)	.10	101	Front Sight Reticule .050" Blade	
75	Front Swivel Screw Washer		TON SERVICE		10
	(341-NRA)	.10	102	Front Sight Reticule .100" Blade	
330	Inner Magazine Tube	.50			10
331	Magazine Follower	.10	Rea 102	r Peep Sight (341-P and 341-NRA)	
32 33	Magazine Pin	.10	103	Rear Peep Sight Disc (small	
33 / 34	Magazine Plug	.10	month of the contract of the c		20
235	Magazine Ring	.30	104	Rear Peep Sight Disc (large	
36	Magazine Spring	.10	105		20
× 85	Magazine Tube Support Screw	.10			20
337	Main Spring	.10	106		50
90	Main Spring Abutment Pin		107		0
338	Main Spring Plunger	.10	108		0
339	Outer Magazine Tube	1.00	109	Rear Sight Elevation Plate	0
24 l	Rear Signt Leaf	.40	110	Rear Sight Elevation Plate Screw	
42	Rear Sight Screw (2)	.10		(2)	0
343	Rear Sight Step	.10	111	Rear Sight Windage Plate	0
344	2 Receiver (complete)	3.00	112	Rear Sight Windage Plate Screw	
444 !	名 Receiver (341-P and 341-NRA)	3.00	20 - 10 - 10 - 10 - 10 - 10 - 10 - 10 -	(2)	0
923	Safety (complete)	.80	103 1/2	Rear Peep Sight (complete)	0

REMINGTON ARMS COMPANY, INC.

Firearms Value & Reference Books

NOTE: We do not provide information on firearms' values. You may want to have your firearm appraised by a gunsmith. The following sources may also be helpful. We do not accept responsibility for the goods or services provided by these sources.

Firearms Value Books

Blue Book of Gun Values
Blue Book Publications
8009 34th Avenue South #175
Minneapolis, MN 55425
800-877-GUNS

Flayderman's Guide to Firearm Values
Gun List
Modern Gun Values
Krause Publications
700 East State Street
Iola, WI 54990-0001
847-573-8530

Gun Trader's Guide Stoeger Publishing Company 5 Mansard Court Wayne, NJ 07470 973-872-9500

Reference Books

The Remington 700
John Flacy
Brownells, Inc.
200 South Front Street
Montezuma, IA 50171
515-623-5401

Frank C. Barnes
Standard Catalog of Firearms
Krause Publications
700 East State Street
Iola, WI 54990-0001
847-573-8530

Shooter's Bible
Stoeger Publishing Company
5 Mansard Court
Wayne, NJ 07470
973-872-9500

Remington, America's Oldest
Gunmanker
Remington Arms Co.
PO Box 700
Madison, NC 27025
Attention: History Book
800-423-8495

Cartridges of the World

Frearing Value & Reference Books

1851-Et. We discut previous submaration on themselved values. You may want to have your firecam 10p. and by a grimmalist. The following sources may also be nefulled. We do not accept nonmanished for the growth at services provided by these sources.

Favorise Value found

Ginn Book of One Values

Bine Book Individues

Fille subsections Sangette 15

Fillen supported as the

Fillen supported as the

Fillen supported as the

Paper sea 's caide a firearm Values
Con List
Naces a Gran Value
Not and Publications
Not Fast State Street
Load, W. 50990-0001

Gap Lad**er's** Greek Sineset Problemics Congress Sineset Court Wayne, M. 19750 47-872**-95**00

Reference Books

uno Remington 1985 John Fürr Strongent, inc. 200 Sande Pront Strock Plantes and Pront Strock

Continues of the Wester Proof Contains Searched Contains of Presents Render Publications 710 Feet State Street Poles VI Feet-CCU

> Special Stible Sweger tublishing Company Stranga Court Wayne W. 07470 973-971-5500

Cemiosios enerica's Oldosi Cunaracius Peninglos Arias (10 Arialisan, No. 27025 Middisan, No. 27025 Attentos History kook