

HIVIZ® ETA™ FLUORESCENT LITEPIPE **FRONT SIGHT KIT INSTALLATION GUIDE** **(FOR GUNS SO EQUIPPED)**

IMPORTANT! Read all instructions and warnings in this insert and in the Owner's Manual before using your Shotgun. Keep this insert with your Owner's Manual at all times. If you sell or transfer your firearm to someone else, be sure to provide them with the Owner's Manual and this insert.

If your shotgun comes equipped with HIVIZ® Fluorescent LitePipe Sight a large diameter fluorescent green LitePipe is already installed. Also provided is a sight kit containing several additional light pipes in a handy carrying case.

TO INSTALL A HIVIZ® ETA™ SIGHT:

- ⚠ WARNING!**
1. Make sure the shotgun is completely unloaded.
 2. Always check the chamber and magazine to make sure there are no cartridges in the shotgun.
 3. Point the shotgun in a safe direction.
 4. Engage the safety mechanism in the "Safe" or "On" position.
- RED BAND WILL NOT SHOW.**

1. Snap a base and sight unit. Slide slight forward until it contacts conventional sight.

TO CHANGE LitePipe:

1. Follow safety measures above.
2. Push front of sight with your thumb or forefinger to disengage it from keyway, lifting gently from back of LitePipe.
3. Remove sight from retaining loops.
4. When installing new sight, be sure to align key on sight with keyway on base.

If your firearm is subject to rain or snow, remove the LitePipe following the instructions and safety precautions listed above. Once the LitePipe is removed, clean and lubricate the interface between the sight base and vent rib. Some lubricants and solvents may harm the LitePipe sight. RemArms recommends placing a drop of oil at the interface between the sight base and the vent rib to inhibit corrosion. Once the area is lubricated, re-install the sight following the instructions above. **NOTE: When base is removed from shotgun and LitePipe is removed from base, the exclusive floating magnet system may drop from the base.**

