Remington Arms Company, Inc. 870 Remington Drive PO Box 700 Madison, NC 27025-0700 (336) 548-8700 800-243-9700

# REMINGTON

# Arms Company, Inc.

# MODEL 10 PUMP ACTION SHOTGUN

- Shooting Safety Commandments
- Information
- Instructions for Operation & Care of Rifle
- Components Parts Listing
- · Value and Reference Book Listing

NOTE: We are pleased to accommodate your request for the Model 10 Pump Action Shotgun information. The following documentation represents all information available on this model from the Remington Arms Co., Inc.

DO NOT MAKE CHANGES OR ALTERATIONS TO ANY PARTS OF A FIREARM. USE ONLY REMINGTON PARTS. NEVER MAKE AN ADJUSTMENT TO THE TRIGGER, OR CHANGE THE SHAPE OR SIZE OF THE SEAR, SEAR NOTCH, OR OTHER PARTS.

### Ten Commandments of Shooting Safety

1. Always keep the muzzle pointed in a safe direction. 2. Firearms should be unloaded when not in use. 3. Don't rely on your gun's "safety". 4. Be sure of your target and what is beyond it. 5. Use correct ammunition. 6. If your gun fails to fire when the trigger is pulled, handle with care! 7. Always wear eye and ear protection when shooting. 8. Be sure the barrel is clear of obstructions before shooting. 9. Do not alter or modify your gun, and have guns serviced regularly. 10. Learn the mechanical and handling characteristics of the firearm you are using.

# Remington Repeating Shotgun

"Pump Action"

Solid Breech

Hammerless

Take-Down

Made in 12 Gauge Only

HE Remington 1908 Model, solid breech, hammerless, take-down, six-shot repeating Shotgun is an example of the highest development of the gunmakers' art. It embodies many new and novel features and eliminates those which are objectionable in repeating shotguns of the present day. Beauty of design, perfection of workmanship and finish are strikingly apparent. Absence of projecting parts adds symmetry to its altogether pleasing and graceful lines. It handles fast and balances perfectly, due in large measure to the grip of stock being more nearly in line with the barrel than any other design of repeating shotgun yet produced. Operation of the mechanism causes no change in the exterior appearance of the gun, excepting in the position of the slide-handle or fore-arm, which is not unsightly.

SOLID BREECH

The design of receiver or frame provides for a SOLID BREECH. There are no openings in top or sides of receiver to weaken it, or allow dirt, snow, rain or

other foreign substance to reach the mechanism, to rust or prevent its working under all conditions. But a feature of much GREATER IMPORTANCE to the shooter and one to which we desire to draw ESPECIAL ATTENTION, is the fact that the receiver is ABSOLUTELY SOLID in the rear. The breech block does not slide out, nor is there an opening of any description

at this point, affording absolute protection no matter what may occur against the breech block, firing-pin, powder gases, defective primers, grease, etc., from blowing back into the eyes or face of the shooter with attendant liability of serious injuries.

The loading and ejecting of shells is done through an opening in the under side of receiver, with the advantage that ejected shells are kept away from the face of the shooter and from interfering with the aim,

erless feature affords pro-

HAMMERLESS

The hammerless feature affords protection from liability of accidental discharge common to repeating guns of the hammer type and the absence of a projecting hammer adds greatly to the attractive appearance of the gun.

# igion Repeating Shotgun

" Pump Action"



Cut No. 1

of stop lugs on magazine IN GUN CLSE TO PLACE GUN hold slide handle forward rearward until stopped and and turn magazine a quarter turn by means of lever. place. Action bar is thus protected, as shown in Cut Turn magazine lever into

# Directions for Operating

MAGAZINE down. Place shells on breech block and push well into magazine Close action by pushing slide handle forward. Turn gun upside which-holds five shells.

TO LOAD BARREL Press the button on right side of receiver and move slide FROM MAGAZINE handle smartly rearward and forward.

WHEN LOCKED TO MAKE "SAFE" Push safety slide (No. 53) rearward and the trigger will be locked.

TO OPEN GUN WHEN COCKED

pleted; otherwise the empty shell will be elected without feeding the next loaded from the magazine. Be sure to bring back the slide as far as it will go. shell from the magasine. Be sure to bring back the slide as far as it will go. ceiver and move slide handle rearward. After firing a shell Press action bar lock button (No. 3) on right side of rebe sure the full rearward movement of the slide is com-

SHELLS FROM CHAMBER TO REMOVE LOADED

drawn from the barrel by this operation) at the opening in the bottom of the and catch the loaded shell (which will be withaction by pulling slide handle back rather slowly Press button on right side of receiver and open

SHELLS FROM MAGAZINE TO REMOVE LOADED

operation will move slide handle slightly forward; by moving it rearward the ceiver and with the fingers remove the shell which lies above the carrier. next shell is released from the magazine and may be removed in the same manner Repeat until the magazine is empty. Keep gun right side up when removing which will release the next shell from the magazine; then push carrier up against side of re-Complete the rearward movement of slide handle

-

# ngton Repeating Shotgun

Directions for Setting Up and Taking Down

TOGETHER Pull magazine (No. 47), which will release magazine lever (No. 40). of this lever unacrew magazine (No. 47) a quarter turn. Push slide handle TO PUT GUN (No. 34) forward until end of magazine is even with barrel yoke (No. 12). Push over magazine lever descut (No. 14) on front end of as difficulty will be experienced in putting gun to-

TOGETHER.

BEFORE ATTEMPTING Rether if cocked. Snapping the trigger before striking front end on palm. Grasp the barrel near breech with left band (Cut block is not in forward position, jar into place by holding receiver downward assembling the gun will not be detrimental to the arm. Breech Block (14) must be forward and held firmly against Top of Receiver (No. 53). If breech

sition with the right hand. and magazine forward as No. 2), holding slide handle pressing thumb through the receiver in an inverted pofar as possible. Hold the and against Top of Reopening in under side to hold Breech Block forward

ceiver. Enter barrel with magazine outward, as shown in Cut No. 2, until the

barrel yoke is firmly against the face of the receiver. until the qualifying lines on under side of barrel yoke and receiver meet (Cut. No. 3) Still holding Breech Block against top of slide handle back until action Receiver with thumb, pull Screw a quarter turn

zine into receiver and screw a quarter turn By means of magazine lever, push maga-Turn magazine lever into place. block and starts it rearward

WWW bar (No. 1) engages breach

Cut No. 8

TO TAKE CON DOWN tent on front end of magazine, which will release magazine Push over magazine lever de-

lever out until stopped (Cut No. 1). By means of this lever, unscrew maga-nummumum zine a quarter turn. Push slide handle forward until

a quarter turn (Cut No. 2), and pull out of receiver magazine near receiver (Cut No. 3), unserew barrel free from receiver (Cut No. 3). Grasp the barrel and magazine and action bar are

Cat No. 1

## Remington Repeating Shotgun

(Pump Action)


Solid Breech

64

Hammerless

Take-Down

Made in 12 Guage Only



Furnished with solid ribbed barrel instead of plain at an advance of \$6.75 list.

A six shot repeater designed especially for trap shooting purposes. This grade differs from No. 3 "Trap in that the stock and fore-arm are American Walnut, the stock being furnished in but one dimension which is 14 inches in length, drop 2 inches at heel and 1½ inches at comb. The majority of trap shooters have found these dimensions to be the best adapted for trap shooting purposes. The barrel is of Remington steel and the top surface is neatly matted its entire length which prevents the reflection of light that might interfere with the shooter's sighting. It also aids in taking quick and accurate aim. The barrels of the "Trap Special" are especially selected for trap loads and all guaranteed to shoot over 70% of the load in a 30-inch circle at 40 yards.


# Remington Repeating Shotgun

(Pump Action)


Solid Breech

Hammerless

Take-Down



Six shot repeater, 20, 22, 30 and 32 inch Remington steel barrel, any desired choke. Stock and fore-arm are of the choicest Imported walout, handsomely checkered by hand, silver name plate inlaid in stock. The barrel and receiver are finished with a beautiful deep scroll hand engraving with panel on left side of receiver. All working parts are hand polished. Stock dimensions are same as No. 4 Tournament grade. Made in 18 gauge only.



The No. 6 "Premier" grade Pump gun, like our No. 6 Autoloading shotgun, is a work of art, so effort being spared to produce the finest gun in both workmanship and finish as it is possible for a factory to turn out. The receiver and berrel are finished in a beautiful deep scroll hand engraving which brings out the game panels in relief. Owner's initials engraved on name plate, if an desired. Stock dimensions same as No. 4 Tournament grade. Made in 12 gauge only.


# Remington Repeating Shotgun

(Pump Action)

Solid Breech

Hammerless

Take-Down



No. O "Riot " Grade, -

List, \$27

This Gun furnished with 20-Inch Cylinder Barrel only

The Riot grade pump gun is lored especially to shoot buckshot. It is being used in a number of State prisons also by express mecacagers and watchmen. It is a six shot repeater made in 12 gauge only. Stock dimensions same as No. 1 Standard grade.

#### Matted Ribbed Barrel



Solid matted rib, advance of \$6.75 list.

The matted ribled farred is particularly appreciated by shouters who have used a double gun and therefore are accustomed to a continuous line of sight, it also prevents the reflection of light on the top of the barrel from interfering with the shooters sight. Trap shooters especially find this feature being to increase their secure. The larrel and rib are made in one solid pieces hence we cannot fit a rib to a plain barrel.

Nore - See Instructions on ordering extra barrels as given on pages 8. 40 1/80 8 20 18 18 18 18 18


# Remington Repeating Shotgun

(Pump Action)

Solid Breech


Hammerless E

Take-Down



Furnished with matted ribbed barrel instead of plain at an advance of \$6.75 list.

Six shot repeater, 28, 28, 30 and 32 inch Remington steel barrel any desired choke. 30 inch full choke sent unless otherwise specified. Half-pistol grip stock and fore-arm of American walnut, regular dimensions 13½ inches long; drop at heel 2½ inches, drop at comb 1½ inches. Any other length or drop of stock made to order at an advance of \$10.




Furnished with matted ribbed barrel instead of plain as an advance of \$6.75 list.


Same as No. 1 Standard grade with the exception that the stock and fore-arm are of selected Imported walnut, half-pistol grip and fore-arm are neatly checked. Will furnish made to order, without extra charge, lengths from 13½ inches to 15 inches, drops 2½ inches to 3½ inches at the heel. Any other length or drop of stock made to order at an advance of \$10.

Norz.-For extres on Pump gun refer to page 69.

### COMPONENT PARTS

Model 10 Repeating Shotgun





REMINGTON ARMS COMPANY, INC.

Remington Ilion Works Ilion, N. Y., U. S. A.

# LIST OF COMPONENT PARTS

# MODEL 10 REPEATING SHOTGUN

No.	··· .						
*****	Part		1	۲o,	Part		
U-I	Action Re-						
U-1	Grade 10 1	Grade A.B.C. \$	t	J-87	Fa 1	. =	
U-1	Grade 10.1	O		7-75	Ристепа Ристепа	Sut	\$
∴ U-1		<u> </u>					
್ U-2 ⅓	Action P	ock				102 111-4 12 7	· ·
U-3'#	Action Ban 1	ock Button			- variu, CF	10e 70.5	
( 13° ) ( 10° )	complete	ock Button,			- unit u. U.F.	ICA IO-R	
U-21/	Action Bar !	ock, complete.	e e e	-74×/ C		de 10-F	5.5.5.4.c.
U-5	***************************************	AA9-D:	A PARTY D	-71% C			
U-69			L. C.	-106 T			
Ų:6			U	-107 L	atch Pia	ech Block)	
Ų.7	Action Bar S	rud	יַ עַ		aich Cas	e dinan	
U-8			<b>U</b>		lain Shein	<b>C</b> errit in the s	
U-103			U.	40 N	lacazine I	g .	
U-10	Barrel Adjust	Dr Buching		41 M	lagazine T	ever.	1000年度12年 - 1870年 第二章
U-83			U	42 🗀 M	agazine 1	ever Pin	
· U-11			U-	44 . M	lagazine I.	ever Spring	• •
U-+3	Screw	natified Fock	ַָּטַ	44% M	agazine L.	ver Detent	* · ·
U-45	Barrel Lug Barrel Lug S		$u_{i} = u_{i}$				
U-80	Barrel Lug S	rew	U-				
D-13			U-		THE PARKET P.	l II oʻ	
U-12			U-				
U-12	Grade D	rade M,B,C.,	. <u>U</u> -		- Bacille L	DIIAWas	
U-12	Grade E	******	Ŭ-,				
U-13	Grade E Grade F Barrel Yoke S	***	U-				
U-14	Barrel Yoke S	top Screw	<u>U-</u> .				
U-141/2			Ŭ-1				
U-15			U-8				
U-16"	Butt Plate.	********	U-8				
U-20			U-5				
U-23			U-5				
U-82				~		70.71 n a	
U-25			Ŭ-5		- Contract	P*311 on (4)	
U-251/2			U-6				
U-26	Cocking Head,	complete	Ŭ-6				
U-27	Cocking Head	רוח	Ŭ-6:		· OPTIME .		
U-28	Extractor	*******	Ŭ-1	~	opting :	1 C P # 100	
U-29	Extractor Pin		U-1		YOU CHARGO	I ()= A	
U-ao	Extractor Sprin	<u></u>	U-1		VALUE OF THE	10-R and 0	
			U-12		ck Crade	10-S	
U-82	Firing Pin Bush	· · · · · · · · · · · · · · · · · · ·	U-17	Stoc	rk Cana	10-D	•
			U-17	Stoc	rk Grade	10-E	•
		7 / A	U-18	Stoc	k Roll	10-F	•
	The state of the s	10-12-10-0	U-19	Stoc		**************************************	
U-34 7	Pore end, Grade	10.0	U-68	Tane	E Screw	asher	•
			U-68	Tand	Screw C	cck Screw	• •
	Y F CIU LIPANA	10-22	U-64	Trie	rer	cck Screw	
D-81 E	ore-end, Grade	10-E	U-65	Triz	ger Pin	• • • • • • • • • • • • • • • • • • • •	•
	, 4.476	AV-1,,	U-66	Trigi	ger Sprin-		•
				31	Prival &	********	
	and the second s						

#### EXPLANATION OF OPERATION

Grasp the fore-end firmly and pull back, which moves action bar into receiver. The action bar draws the breech block below the recoil shoulder, is the receiver; at the same time while the block is moving backward, the firing pin, which is in the breech block, is cocked. Near the end of backward stroke the breech block turns the carrier to bottom of receiver, allowing the shell to come from the magazine back upon the carrier. The arm is now in position as shown in "Sectional View," "Action Open."

Pushing the fore-end forward moves the carrier up with the shell until the shell is brought into the barrel and locked there by the breech block. The sea cannot be disengaged from the firing pin, because the trigger cannot reach the sear until the breech block has locked the shell securely in the barrel.

The gun may be made "safe" by pushing the safety toward the rear, when the trigger cannot be pulled. The fore-end cannot be pulled back when the gun is cocked because the action is locked by the action bar lock engaging in slot in side of receiver. This may be released either by firing the arm or by pressing the release button on the right side of receiver, when the action may be opened, if it is not desired to fire the shell.

Assume that the gun has been fired—the arm is then in position as shown in "Sectional View," "Action Closed." Pull back fore-end. The extractor or the front end of the breech block grasps the rim of the shell and pulls it out The shell is held in the top of the receiver by two ribs until drawn fully out or barrel when the extractor, extractor spring and ejector spring, which are in top of the receiver, push the empty shell straight down and out of the button of the receiver.

#### CARE OF FIREARMS

A firearm should be cleaned as quickly as possible after shooting. Delay causes the fouling to become sticky and hard, making removal difficult REMINGTON Powder Solvent is highly recommended for this purpose.

Always clean the barrel from the breech. All REMINGTON firearms are made in Take-Down style so they can be cleaned in this manner. If cleaned from the muzzle the dirt is pushed back into the action and the cleaning rod is apt to bend or break the ejector spring causing failure to operate properly.

Another effective means of cleaning is by the use of boiling water, which should be poured through the barrel.

Care should be taken that the barrel is thoroughly dried, then greased with a heavy grease, preferably REMINGTON Gun Grease.

When the gun is again used the grease should be carefully removed. All mechanism and surfaces should be cleaned and lubricated with a thin oil.

Rem Oil, which has been developed after long and careful experimental work at our arms factory, is highly recommended for this purpose. It is in general use at our plants.

The sear spring located in bottom of breech block should be kept screwed in as far as possible. Do not remove barrel lug screw or attempt to remove barrel lug or barrel yoke, as these have been carefully adjusted by special factory tools.

If stock becomes slightly loose from shrinkage of wood it should be tightened immediately by removing butt plate and turning bolt tightly, using a long screwdriver in deep hole of stock.

#### Firearms Value & Reference Books

NOTE: We do not provide information on firearms' values. You may want to have your firearm appraised by a gunsmith. The following sources may also be helpful. We do not accept responsibility for the goods or services provided by these sources.

#### Firearms Value Books

Blue Book of Gun Values
Blue Book Publications
8009 34th Avenue South #175
Minneapolis, MN 55425
800-877-GUNS

Flayderman's Guide to Firearm Values

Gun List

Modern Gun Values

Krause Publications

700 East State Street

Iola, WI 54990-0001

847-573-8530

Gun Trader's Guide
Stoeger Publishing Company
5 Mansard Court
Wayne, NJ 07470
973-872-9500

#### Reference Books

The Remington 700
John Flacy
Brownells, Inc.
200 South Front Street
Montezuma, IA 50171
515-623-5401

Cartridges of the World
Frank C. Barnes
Standard Catalog of Firearms
Krause Publications
700 East State Street
Iola, WI 54990-0001
847-573-8530

Shooter's Bible Stoeger Publishing Company 5 Mansard Court Wayne, NJ 07470 973-872-9500 Remington, America's Oldest
Gunmanker
Remington Arms Co.
PO Box 700
Madison, NC 27025
Attention: History Book
800-423-8495